

Geographical Information Systems (GIS)

Section 8

By: Abdelrahim Alsadiq





Table of Contents


- 1. Understanding Latitude and Longitude
- 2. Getting Coordinates from Google Maps (Mobile)
- 3. Install Numerical Digitze Plugin
- 4. Adding point feature from coordinates

1. Understanding Latitude and Longitude

- Geographic coordinates are a way to describe a specific location on Earth using numbers.
- This system uses two values:
 - Latitude (Y-axis):
 - Measures how far north or south a point is from the Equator.
 - Ranges from -90° to +90° 0° is the Equator Positive values are north, negative values are south
 - Congitude (X-axis):
 - Measures how far east or west a point is from the Prime Meridian (which runs through Greenwich, UK).
 - Ranges from -180° to +180° 0° is the Prime Meridian Positive values are east, negative values are west

2. Getting Coordinates from Google Maps (Mobile)

- 1. Launch the Google Maps app on your smartphone.
- 2. Tap and hold on a specific point on the map where you want to get the coordinates.
- 3. Swipe up on the location card (or tap it) to expand it.
- 4. You'll see the latitude and longitude displayed under the address or name






2. Getting Coordinates from Google Maps (Mobile)

Google Maps uses (EPSG:4326 WGS 84) as CRS.

- If your project different from this CRS, then you need to convert what you got from Google Maps to suitable values for your CRS (for example: Egypt uses EPSG:4229)
- To convert from one CRS to other, you can use <u>epsg.io.</u>
 - Make sure you get values in dec format







3. Install Numerical Digitze Plugin


Usage: allows users to enter precise coordinates or distances and angles when digitizing points, lines, or polygons, enabling accurate and controlled feature creation


How to Install Plugin:

- 1. First, go to plugins -> Manage and Install Plugins.
- 2. Search for NumericalDigitze and install it.
- 3. After installing it, you'll notice that toolbar has 2 new options:










4. Adding point feature from coordinates

- 1. You'll have to create a new shapefile point layer with a name field as well.
- 2. Go to Layer > Create Layer > New Shapefile Layer.
- 3. Select "Point" as shape type.
- 4. Add a name field and change the directory using ... on the right.
- 5. Select an appropriate data type.
- 6. Change length value when needed.
- 7. On "add fields list", add attributes that you prefer in each point.

Note: Make sure you change the saving directory before pressing "Ok".

Note: Choose a CRS that is compatible with the project's CRS



4. Adding point feature from coordinates

- 1. Now, right click on the layer and click on "Toggle Editing".
- 2. Selecting Toggle Editing produces a pencil icon to the right of the "Layers Panel".
- 3. Make sure your new layer is still highlighted, and in the toggle editing mode.
- 4. Click on the "Numerical Digitze" points layer on the menu above the layers panel.
- 5. Now enter the values (must be in dec format) of:
 - 1. Longitude (X)
 - 2. Latitude (Y)

